

# **Universal Remote Code Book**

TV					
A					
ACER	1484				
ACME	0013				
ADA	0008				
ADC	0012	0008			
ADMIRAL	0019	0108	0002	0001	0047
	0000				
ADYSON	0003				
AGAZI	0002				
AGB	0123				
AIKO	0003	0009	0004		
AIWA	0184	0248	0291		
AKAI	1410	0011	0086	0009	0068
	0004	0006	0008	0051	0061
	0088	0169	0200	0133	0141
	0069				
AKIBA	0011				
AKURA	0169	0074	0002	0009	0011
	0071				
ALBA	0028	0027	0009	0011	0003
	0068	0083	0169	0047	0245
	0248	0162	0062		
ALBIRAL	0037				
ALKOS	0164				
ALLORGAN	0157	0026			
ALLSTAR	0051				
ALTUS	0042				
AMPLIVISION	0003				
AMSTRAD	0011	0009	0068	0074	0002
	0108	0071	0069	0030	0123
	0013				
ANAM	0009	0065	0109		
ANGLO	0009				
ANITECH	0009	0002	0043	0109	
ANSONIC	0009	0014			
AOC	0134				
ARC EN CIEL	0126	0045	0139		
ARCAM	0003				
ARISTONA	0169	0051			
ARTHUR MARTIN	0158				
ASA	0017	0110	0016	0018	0000
	0021				
ASBERG	0051	0043			
ASTRA	0009				
ASUKA	0011	0002	0003		
ATLANTIC	0169	0003	0051	0157	
ATORI	0009				
AUDIOSONIC	0009	0003	0169	0011	0051
	0139	0157	0090		
AUDIOTON	0003				
AUSIND	0043				
AUTOVOX	0003	0002	0101	0157	0000
	0125	0043			
B					
BAIRD	0111	0139	0245		
BANG & OLUFSON	0199	0000			
BARCO	0112				
BASIC LINE	0009	0011	0051	0245	
BASTIDE	0003				
BAUR	0169	0118	0076	0141	0132
BEKO	0042	0083	0034	0095	1064
	0007				
BEON	0169	0051			
BEST	0113				
BESTAR	0051	0245			
BINATONE	0003				
BLACK DIAMOND	0171				
BLACK PANTHER LINE	0245				
BLACK STAR	0129				
BLAUPUNKT	0117	0202	0135	0008	0022
	0100				
BLUE SKY	1485	0156	0011		
BLUE STAR	0120				
BLOOM	0015				
BONDSTEC	0129				
BOOTS	0003				
BPL	0120				
BRANDT	0127	0045	0022	0036	0126
	0139	0046			
BRION VEGA	0051	0169	0000		
BRITANNIA	0003				
BROKSONIC	0920				
BRUNS	0000	0007			
BSR	0131	0026			
BTC	0011				
BUSH	0028	0027	0032	0009	0011
	0019	0205	0039	0051	0068
	0169	0107	0115	0131	0139
	0167	0245	0248	0024	0132
	0120	0062			
C					
CAPSONIC	0002				
CARREFOUR	0027				
CASCADE	0009				
CATHAY	0051	0169			
CENTRUM	0168	0205			

CENTURION	0051	0169			
CENTURY	0000				
CGE	0129	0047	0131	0043	
CIMLINE	0009	0028			
CITY	0009				
CLARIVOX	0169	0037			
CLATRONIC	0009	0011	0051	0002	0083
	0003	0129	0030	0043	
COMBITECH	0248				
CONCORDE	0009				
CONDOR	0198	0051	0083	0003	0245
CONRAC	0038	1395			
CONTEC	0003	0009	0027	0030	0029
CONTINENTAL EDISON	0022	0111	0036	0045	0126
	0139	0046			
COSMEL	0009				
CPRTEC	0156				
CROSLEY	0129	0131	0000	0043	
CROWN	0009	0169	0083	0047	0051
	0245	0121	0043		
CS ELECTRONICS	0011	0129	0003		
CTC	0129				
CTC CLATRONIC	0014				
CYBERCOM	0177	0038	0171	0002	0009
	0206	0205	0207	0208	0210
	0169	0042	0044	0127	0047
	0061	0063	0067	0068	0103
	0107	0115	0154	0168	0185
	0228	0209	0343	0924	0933
	0248	0291			
CYBERMAXX	0177	0038	0171	0002	0009
	0206	0200	0205	0207	0208
	0210	0211	0169	0015	0042
	0044	0047	0048	0049	0061
	0063	0067	0068	0087	0103
	0107	0115	0127	0154	0155
	0168	0170	0185	0228	0229
	0209	0218	1005	0894	0343
	0924	0933	0248	0291	
CYBERTRON	0011				
CYTRON	0177	0038	0171	0002	0009
	0206	0200	0205	0207	0208
	0210	0211	0169	0015	0042
	0044	0047	0048	0049	0061
	0063	0067	0068	0087	0103
	0107	0115	0127	0154	0155
	0168	0170	0185	0228	0229
	0209	0218	1005	0894	0343
	0924	0933	0248	0291	
D					
DAEWOO	0094	0009	0191	0003	0051
	0115	0245			
DAINICHI	0011				
DANSAI	0002	0169	0051		
DANTAX	0171	0161	0169	0088	0034
	0113				
DATSURA	0121				
DAYTON	0009				
DAYTRON	0245				
DCE	0205	0042			
DE GRAAF	0019	0006	0033		
DECCA	0003	0169	0004	0051	0123
	0030				
DECCACOLOR	0015				
DELL	0025				
DESMET	0051	0169			
DIGITOR	0227	0228			
DISNEY	0148				
DIXI	0009	0169	0051		
DTS	0009				
DUAL	0177	0038	0171	0002	0009
	0206	0207	0208	0169	0042
	0044	0127	0047	0061	0063
	0067	0068	0003	0103	0107
	0115	0126	0131	0139	0154
	0160	0168	0210	0228	0343
	0924	0933	0248	0291	0125
	0089				
DUAL-TEC	0009	0131	0003		
DUMONT	0003	0014	0017	0018	0000
DURABRAND	0228	1006	1007	1008	1009
	0933	1088			
DUX	0169				
DYNATRON	0051	0169			
E					
ELBE	0108	0157	0037		
ELCIT	0000				
ELECTRO TECH	0009				
ELEKTA	0120				
ELIN	0051	0003	0169	0016	0018
ELITE	0011	0051			
ELMAN	0014	0131			
ELTA	0009				
EMERSON	0141	0127	0000		
ERAE	1003				
ERRES	0169	0051			
ESC	0245				
ETRON	0009				

EURO-FEEL	0002				
EUROLINE	0149	0169	0088		
EUROMANN	0002	0051	0003		
EUROPHON	0003	0014	0051	0131	0123
EXPERT	0157				
<b>F</b>					
FAIRTEC	1485	1416	0204	0156	
FENNER	0009	0115			
FERGUSON	0127	0166	0035	0169	0036
	0050	0052	0111	0163	0037
FIDELITY	0003	0019	0068	0074	0096
FINLANDIA	0019	0006	0110	0128	
FINLUX	0061	0087	0063	0003	0004
	0016	0167	0110	0131	0157
	0169	0051	0017	0018	0014
	0042	0000	0123	0043	
FIRSTLINE	0156	0003	0129	0009	0051
	0062	0026			
FISHER	0006	0003	0018	0083	0131
	0000	0027	0029	0040	
FLINT	0051	0113			
FORMENTI	0001	0169	0003	0131	0133
	0000	0043	0125		
FORTRESS	0001	0000			
FRONTECH	0019	0002	0009	0068	0118
	0129	0120	0021		
FUJITSU	0116	0004	0157		
FUNAI	0002	0026			
<b>G</b>					
GALAXY	0047	0083			
GBC	0009	0027	0131		
GEC	0169	0003	0004	0041	0051
	0141	0123	0132		
GELOSO	0019	0009	0131		
GENERAL TECHNIC	0009	0248			
GENEXXA	0011	0051	0021		
GERICOM	1064	0049	1022	1023	
GOLDSTAR	0084	0129	0003	0009	0019
	0051	0131	0169	0171	0261
	0012	0093			
GOODMANS	0009	0111	0002	0004	0027
	0169	0028	0051	0068	0115
	0127	0171	0245	0283	0093
GORENJE	0083				
GPM	0011				
GRAETZ	0141	0142	0021		
GRANADA	0127	0019	0003	0006	0169
	0027	0031	0051	0054	0004
	0064	0133	0138	0128	0040
	0043	0123			
GRANDIN	0009	0169	0011	0245	0120
GRUNDIG	0117	0091	0114	0101	0135
	0008	0017	0136	0043	
<b>H</b>					
H & B	0343	0228			
HB	1003	0168	0095	0015	0042
	1011	1020	1389		
HAAZ	0228				
HALIFAX	0002	0003			
HAMPTON	0003				
HANSEATIC	0009	0003	0027	0169	0051
	0083	0118	0131	0141	0007
	0026				
HANSOL	0109				
HANTAREX	0009	0123			
HARWOOD	0171				
HCM	0002	0003	0009	0074	0120
HIFVOX	0139				
HINARI	0171	0009	0011	0027	0051
	0006	0169	0248	0043	0137
HISAWA	0011	0113	0120		
HISENSE	1486	1485	1417	1416	1415
	0204	0156			
HITACHI	0027	0019	0085	0134	0153
	0213	0140	0144	0003	0118
	0004	0016	0023	0041	0045
	0047	0131	0133	0138	0139
	0141	1013	0021	0046	0033
	0123	0142			
HORNYPHON	0051				
HOSHAI	0011				
HUANYU	0003	0115			
HYGASHI	0003				
HYPHER	0003	0009	0129	0131	
HYPSON	0002	0003	0051	0169	0120
HYUNDAI	1010				
<b>I</b>					
ICE	0009	0002	0003	0011	0051
	0068				
IJYAMA	1414				
IMPERIAL	0047	0051	0083	0129	0131
	0021	0043			
INDESIT	0024	0101			
INDIANA	0051	0169			
INGELEN	0021				
INGERSOL	0009				
INNO HIT	0009	0011	0003	0004	0051
	0169	0245	0093	0123	

INNOVATION	0171	0111	0002	0009	0169
	0061	0067	0068	0103	0107
	0115	0154	0168	0177	0248
	0291				
INTERBUY	0009	0129	0109		
INTERFUNK	0051	0129	0169	0139	0141
	0000	0021			
INTERTRONIC	0894				
INTERVISION	0002	0003	0014	0109	
IRRADIO	0009	0011	0051	0169	0068
ISUKAI	0011				
ITC	0003	0131			
ITS	0011	0051	0068	0120	
ITT	0061	0009	0143	0031	0133
	0141	0021	0142	0132	
ITT/NOKIA	0133	0142	0021		
ITV	0169	0171	0009	0088	0245
<b>J</b>					
JEC	0164				
JVC	0051	0053	0027	0068	
<b>K</b>					
KAISUI	0009	0011	0003	0120	
KAMOSONIC	0003				
KAMP	0003				
KAPSCH	0157	0021			
KARCHER	0169	0003	0009	0016	0037
KENDO	0019	0014	0028	0108	0245
KENNEDY	0131	0157			
KINGSLEY	0003				
KING TV	0015				
KNEISSEL	0174				
KOLSTER	0051				
KONKA	0047	0068	0229	0011	
KORPEL	0051	0169			
KORTING	0000				
KOYODA	0009				
KTV	0003				
KURO	0121				
KYOTO	0037				
<b>L</b>					
LENCO	0009	0245			
LENOIR	0003	0009			
LESA	0129				
LEYCO	0169	0002	0004	0051	0026
LG	0084	0119	0129	0149	0019
	0003	0051	0088	0131	0169
	0171	0009	0261	0093	
LIESENK	0169				
LIFE	0002	0009	0061	0067	0068
	0103	0107	0111	0115	0154
	0168	0169	0171	0177	0205
	0291				
LIFETEC	0177	0038	0171	0002	0009
	0206	0205	0207	0208	0210
	0211	0169	0015	0042	0044
	0047	0048	0049	0061	0063
	0067	0068	0087	0103	0107
	0115	0127	0154	0155	0168
	0170	0185	0228	0229	0209
	0218	1005	0894	0343	0924
	0933	0248	0291		
LOEWE	1399	0097	0098	0051	0169
	0000				
LOGIK	0030				
LS ELECTRONIK	0042				
LUMA	0019	0169	0141	0157	
LUMATRON	0002	0171	0109	0088	0051
	0074	0169	0107	0141	0157
	0245				
LUX MAY	0051				
LUXOR	0141	0019	0047	0003	0077
	0138	0093	0132		
<b>M</b>					
M+P	0133				
MAGNADYNE	0014	0129	0131	0169	0000
	0123				
MAGNAFON	0003	0014	0043	0123	
MAGNUM	0002	0111	0009	0169	0171
	0061	0067	0068	0103	0107
	0115	0154	0168	0177	0200
	0291				
MANDOR	0002				
MANESTH	0002	0169	0003	0028	0051
MARANTZ	1482	0051	0169		
MARELLI	0000				
MARK	0051	0169			
MATSUI	0173	0099	0091	0027	0180
	0028	0147	0003	0004	0009
	0019	0051	0068	0101	0164
	0169	0248	0113	0123	0013
	0062	0026	0030		
MATSUSHITA	0065				
MAXMEDIA	0115				
MCMICHAEL	0041				
MEDIATOR	0051	0169			
MEDION	1419	1397	1395	1002	1001
	0177	0038	0171	0002	0009
	0206	1015	0200	0205	0207

	0208	0210	0211	0169	0015	PATHE CINEMA	0003	0083	0131	0037		
	0042	0044	0047	0048	0049	PATHE MARCONI	0022	0045	0126	0139	0037	
	0061	0063	0067	0068	0087		0046					
	0103	0107	0115	0127	0148	PAUSA	0009					
	0154	0155	0168	0170	0185	PERDIO	0004					
	0228	0229	0209	0218	1005	PHILCO	0047	0129	0131	0000	0043	
	0894	0343	0924	0933	0248	PHILHARMONIC	0003					
	0291	1014				PHILIPS	0200	0088	0217	0202	0020	
MELECTRONIC	0009	0016	0169	0018	0003		0169	0003	0041	0181	0051	
	0036	0051	0068	0110	0115		0083	0111	0115	0131	0141	
	0139	0021	0109				0154	0000	0043	0089		
MEMOREX	0009	0920				PHOCUS	0042	0095	1064			
MEMPHIS	0004	0009				PHOENIX	0051	0169	0000			
METZ	1398	0205	0058	0038	0201	PHONOLA	0051	0169	0000			
	0135	0107	0151	0152	0000	PIONEER	1482	1418	0010	0145	0036	
	0075						0051	0139	0169	0021		
MICROMAXX	0177	0038	0171	0002	0009	PLANTRON	0002	0051				
	0206	0200	0205	0207	0208	POPPY	0009					
	0210	0211	0169	0015	0042	PORTLAND	0245					
	0044	0047	0048	0049	0061	PRANDONI-PRINCE	0019	0141	0123			
	0063	0067	0068	0087	0103	PRECISION	0003					
	0107	0115	0127	0154	0155	PRIMA	0009	0021				
	0168	0170	0185	0228	0229	PRINZ	0047					
	0209	0218	1005	0894	0343	PROZ	0177	0038	0171	0002	0009	
	0924	0933	0248	0291			0206	0200	0205	0207	0208	
MICROSTAR	0177	0038	0171	0002	0009		0210	0211	0169	0015	0042	
	0206	0200	0205	0207	0208		0044	0047	0048	0049	0061	
	0210	0211	0169	0015	0042		0063	0067	0068	0087	0103	
	0044	0047	0048	0049	0061		0107	0115	0127	0154	0155	
	0063	0067	0068	0087	0103		0168	0170	0185	0228	0229	
	0107	0115	0127	0154	0155		0209	0218	1005	0894	0343	
	0168	0170	0185	0228	0229		0924	0933	0248	0291		
	0209	0218	1005	0894	0343	PROFEX	0009	0141	0043			
	0924	0933	0248	0291		PROFILO	0171					
MINERVA	1015	0101	0135			PROFI-TRONIC	0051					
MINOKA	0051					PROLINE	0004	0051	0062			
MITSUBISHI	0000	0027	0030	0051	0054	PROSONIC	0161	0169	0003	0015	0042	
	0057	0060	0098	0101	0135		0088	0107	0200	0068	0245	
	0205					PROTECH	0002	0003	0009	0169	0014	
MIVAR	0055	0083	0003	0093	0123		0051	0129	0131	0132	0113	
	0043					PROVIEW	1419	1002	1001			
MOTION	0043					PROVISION	0169	0171	0015			
MT LOGIC	0090					PYE	0169	0051	0068			
MTC	0132					PYMI	0009					
MULTI SYSTEM	0169					Q						
MULTITECH	0003	0009	0014	0019	0169	QUADRO	0205					
	0027	0045	0129	0131	0043	QUASAR	0129					
MURPHY	0003	0133	0018			QUELLE	0169	0205	0002	0003	0016	
N							0022	0051	0129	0131	0135	
NAD	0141						0141	0017	0018	0026	0030	
NAIKO	0099					QUESTA	0027					
NAONIS	0019	0108				R						
NATIONAL	0064	0101				RADIOLA	0051	0169				
NEC	1482	1483	0185	0027	0056	RADIOMARELLI	0129	0000	0123			
NECKERMANN	0003	0169	0008	0019	0022	RADIONETTE	0016	0018				
	0051	0083	0118	0132	0000	RADIOTONE	0051	0007				
NEI	0051	0068	0169	0113		RANK	0017	0027				
NEOVIA	1019					RBM	0017					
NESCO	0129					RCA	0031					
NEW WORLD	0011					REDIFFUSION	0141					
NEWTECH	0009	0051				REVOX	0051	0169				
NEXIUS	0015					REX	0019	0002	0108	0157	0021	
NICAMAGIC	0003					RFT	0000	0007				
NIKKAI	0002	0003	0164	0004	0011	R-LINE	0051	0169				
	0051	0169				ROADSTAR	0002	0009	0011	0245		
NOBLIKO	0003	0014	0043			ROBOTRON	0000					
NOGAMATIC	0139					RTF	0000					
NOKIA	0061	0143	0063	0141	0077	S						
	0133	0031	0021	0132	0142	SABA	0127	0111	0126	0036	0045	
NORDMENDE	1391	1392	1394	0111	0127		0139	0141	0245	0142	0046	
	0036	0045	0051	0126	0139		0000	0123	0021			
	0046	0000	0021	0024		SACCS	0037					
NORDVISION	0169					SAISHO	0028	0002	0003	0009	0248	
O							0030	0123	0013			
OCEANIC	0141	1011	0142	0021	1089	SALORA	0019	0031	0047	0061	0107	
OKANO	0083						0108	0118	0131	0138	0141	
ONCEAS	0003						0093	0121	0128	0132	0021	
ONWA	0069					SAMBERS	1411	0014	0169	0043	0123	
ORBIT	0051					SAMSUNG	0090	0105	0104	0009	0051	
ORION	0099	0147	0159	0009	0212		0172	0083	0002	0160	0003	
	0028	0051	0154	0169	0171		0004	0312	0030	0093		
	0920	0248	0283	0123	0142	SANDRA	0003	0009				
	0030	0013	0062	0075	0026	SANSUI	0051	0920				
ORMOND	0205					SANYO	0004	0006	0031	0003	0027	
OSAKI	0011	0002	0003	0004	0074		0016	0018	0083	0127	0160	
OSO	0011						0131	0029	0030	0040	0043	
OSUME	0004	0029				SAVILLE	0248					
OTTO VERSAND	0003	0169	0008	0001	0027	SBR	0041	0169				
	0051	0076	0111	0118	0131	SCHAUB LORENZ	0141	0202	0205	1003	0168	
	0139	0141	0120	0121	0132		0095	0015	0042	1011	1020	
P							1385	1386	1387	1388	1389	
PACKARD BELL	0204	0203					1390	0021	0142			
PAEL	0003					SCHNEIDER	0177	0003	0169	0011	0051	
PALLADIUM	0003	0083	0012				0068	0131	0139	0160	0245	
PANAMA	0002	0003	0009				0264	0071	0125			
PANASONIC	0065	0067	0064	0197	0072	SCHWAIGER	1024					
	0186	0101	0141	0021	0151	SEG	0171	0002	0205	0003	0169	
	0142	0124	0152				0009	0014	0027	0088	0129	



LIFE	0291	-			
LIFETEC	0248	0291			
LUMATRON	0245	-			
<b>M</b>					
MAGNUM	0291	-			
MATSUI	0248	-			
MEDION	0248	0291			
MICROMAXX	0248	0291			
MICROSTAR	0248	0291			
<b>O</b>					
ORION	0248	0283			
<b>P</b>					
PORTLAND	0245	-			
PRO2	0248	0291			
PROSONIC	0245	-			
<b>R</b>					
ROADSTAR	0245	-			
<b>S</b>					
SABA	0245	-			
SAISHO	0248	-			
SAMSUNG	0312	-			
SAVILLE	0248	-			
SCHNEIDER	0245	0264			
SONOKO	0245	-			
STANDARD	0245	-			
<b>T</b>					
TCM	0248	0291			
TEVION	0248	0291			
THOMSON	0245	-			
<b>U</b>					
UNITED QUICK STAR	0245	-			
<b>V</b>					
VIDEON	0248	-			
<b>VCR</b>					
<b>A</b>					
AIWA	0230	0233	0256	0293	0231
	0248	0291			
AKAI	0300	0329	0307	0237	0236
	0238	0239	0293		
AKIBA	0275				
AKURA	0275	0244	0293		
ALBA	0275	0233	0250	0245	0248
	0246	0247			
ALLORGAN	0311				
AMBASSADOR	0250				
AMSTRAD	0253	0231	0254		
ANITECH	0275				
APEX	0949				
ASA	0257	0256			
ASUKA	0275	0257	0231	0256	
<b>B</b>					
BAIRD	0259	0231	0258	0245	0237
	0293				
BASIC LINE	0275	0233	0250	0245	
BAUR	0263	0257			
BESTAR	0250	0245			
BLACK PANTHER LINE	0245				
BLAUPUNKT	0263	0257	0262	0260	0309
	0325	0271			
BLUESKY	0248				
BONDSTEC	0250				
BRANDT	0303	0305			
BROKSONIC	0277	0967			
BUSH	0275	0233	0245	0248	0246
	0247	0288			
<b>C</b>					
CATRON	0250				
CGE	0231	0293			
CIMLINE	0275	0233			
CINEVISION	0256				
CLATRONIC	0250				
COMBITECH	0248				
CONDOR	0250	0245			
CROWN	0275	0250	0245		
CYBERCOM	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
CYBERMAXX	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
CYTRON	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
<b>D</b>					
DAEWOO	0274	0250	0265	0319	0245
	0971				
DANSAI	0275				
DANTAX	0233				
DAYTRON	0245				
DE GRAAF	0266	0257			
DECCA	0257	0231	0293		
DUAL	0233	0256	0257	0311	0262
	0319	0293	0248	0291	0338
	0905	0906			
DUMONT	0266	0257	0231	0258	
<b>E</b>					

ELTA	0275				
EMERSON	0231	0256	0301	0339	
ESC	0245				
ETZUKO	0275				
<b>F</b>					
FERGUSON	0294	0259	0271	0278	0293
	0281	0305			
FIDELITY	0311	0231			
FINLANDIA	0266	0257	0258		
FINLUX	0266	0298	0257	0231	0258
	0293	0237			
FIRSTLINE	0266	0275	0233	0265	0298
	0256				
FISHER	0258	0279			
FLINT	0233				
FORMENTI-PHEONIX	0257				
FRONTECH	0250				
FUJITSU	0231				
FUNAI	0231	0339			
<b>G</b>					
GALAXY	0231				
GBC	0275	0250			
GEC	0257				
GELOSO	0275				
GENERAL	0250				
GENERAL TECHNIC	0262	0233	0311	0248	
GOLDHAND	0275				
GOLDSTAR	0231	0256	0261		
GOODMANS	0275	0250	0259	0256	0231
	0245	0283	0282		
GO-VIDEO	0338	0367	0971		
GRAETZ	0258	0293			
GRANADA	0257	0266	0240	0258	0271
GRANDIN	0275	0250	0256	0231	0245
GRUNDIG	0273	0270	0263	0235	0243
	0257	0260	0272	0275	0286
	0287	0290	0315	0271	0288
<b>H</b>					
HAAZ	0233				
HANSEATIC	0257	0256			
HCM	0275	0288			
HINARI	0275	0233	0248	0288	0301
HISAWA	0233				
HITACHI	0266	0257	0268	0231	0293
	0387				
HYPSON	0233	0275			
<b>I</b>					
IMPEGO	0250				
IMPERIAL	0231				
INNO HIT	0250	0257	0275	0245	
INNOVATION	0233	0311	0262	0248	0291
INTERBUY	0256				
INTERFUNK	0257	0258			
INTERVISION	0231				
IRRADIO	0275	0256			
ITT	0237	0293	0258	0292	
ITV	0256	0245			
<b>J</b>					
JVC	0294	0295	0293	0400	
<b>K</b>					
KAISUI	0275				
KARCHER	0257				
KENDO	0233	0250	0265	0300	0245
	0236	0237			
KENWOOD	0293				
KORPEL	0275				
<b>L</b>					
LENCO	0245				
LEYCO	0275				
LG	0231	0256	0261	0907	
LIFE	0291	0256			
LIFETEC	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
LOEWE	0267	0325	0262	0257	0256
	0271				
LOGIK	0275				
LUMATRON	0274	0245			
LUXOR	0298	0258	0237	0281	
<b>M</b>					
MAGNASONIC	0258				
MAGNAVOX	0914	0285			
MAGNUM	0291				
MANESTH	0275	0265			
MARANTZ	0257	0271	0281	0299	
MATSUI	0233	0256	0248	0301	
MEDIATOR	0257				
MEDION	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
MELECTRONIC	0231				
MEMOREX	0240	0256	0231	0258	0279
MEMPHIS	0275				
METZ	0262	0263	0267	0273	0325
	0271				
MICROMAXX	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				

MICROSTAR	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
MIGROS	0231				
MINERVA	0263	0271			
MITSUBISHI	0298	0257	0289	0294	0231
MULTITECH	0275	0250	0257	0231	
MURPHY	0231				
<b>N</b>					
NATIONAL	0262	0260			
NEC	0294	0293	0299		
NECKERMANN	0257	0293	0301		
NEI	0257				
NESCO	0275				
NIKKAI	0250	0302			
NOKIA	0240	0300	0307	0258	0237
	0292	0293			
NORDMENDE	0294	0293	0303	0305	
<b>O</b>					
OCEANIC	0240	0231	0293		
OKANO	0233	0300			
ORION	0234	0233	0304	0248	0283
	0301	0246			
ORSON	0231				
OSAKI	0275	0231	0256		
OTTO VERSAND	0257				
<b>P</b>					
PALLADIUM	0275	0300	0256	0271	0293
PANASONIC	0262	0267	0260	0314	0321
	0325	0970			
PATHE CINEMA	0301				
PATHE MARCONI	0293				
PENTAX	0266				
PERDIO	0231				
PHILCO	0299				
PHILIPS	0235	0257	0290	0315	0327
	0286	0285	0242	0271	0293
	0969				
PHONOLA	0257				
PIONEER	0294	0257	1084		
POLAROID	0949				
PORTLAND	0250	0245			
PRINZ	0231				
PRO2	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
PROFEX	0275				
PROLINE	0231	0288			
PROSONIC	0233	0245			
PYE	0257				
<b>Q</b>					
QUARTZ	0258				
QUELLE	0257	0263	0258	0231	0271
	0301				
<b>R</b>					
RADIOLA	0257				
REX	0293				
RFT	0250	0257			
ROADSTAR	0275	0256	0245		
<b>S</b>					
SABA	0324	0245	0281	0293	0303
	0305				
SAISHO	0275	0233	0248	0301	
SALORA	0298	0258	0237	0292	
SAMSUNG	0311	0312	0338	0963	
SAMURAI	0250				
SANSUI	0294	0244	0293	0920	
SANYO	0284	0258	0279		
SAVILLE	0248				
SBR	0257				
SCHAUB LORENZ	0258	0237	0231	0293	
SCHNEIDER	0275	0233	0265	0250	0257
	0256	0231	0264	0245	
SEG	0275	0319			
SEL-SINUDYNE	0257				
SELECO	0293				
SENTRA	0250				
SETRON	0275				
SHARP	0240	0241	0328	0281	
SHINTOM	0275	0258			
SHIVAKI	0256				
SIEMENS	0263	0256	0258	0271	
SILVA	0256				
SILVERCREST	0256				
SINUDYNE	0257				
SOLAVOX	0250				
SONOKO	0245				
SONOLOR	0240				
SONTEC	0256				
SONY	0232	0308	0309	0310	0313
	0249	0251	0255	0402	
STANDARD	0245				
STRONG	0244				
SUNKAI	0233				
SUNSTAR	0231				
SUNTRONIC	0231				
SUNWOOD	0275				
SYLVANIA	0339	0231			

<b>T</b>					
TAISHO	0233				
TANDBERG	0263				
TARGA	0256	0907	1041		
TASHIKO	0240	0231			
TATUNG	0257	0231	0293		
TCM	0233	0256	0311	0262	0269
	0319	0375	0248	0291	0338
	0905	0906			
TEC	0250				
TECHNICS	0262	0260			
TELEAVIA	0293				
TELEFUNKEN	0306	0294	0324	0295	0323
	0280	0293	0303	0305	
TENOSAL	0275				
TENSAI	0275	0231	0256		
TEVION	0233	0311	0262	0269	0319
	0256	0248	0291	0338	0905
	0906				
THOMSON	0294	0324	0295	0323	0326
	0245	0242	0293	0305	
THORN	0258	0293	0301		
TIVO	0242				
TOKAI	0275	0256			
TONSAI	0275				
TOSHIBA	0320	0257	0265	0298	0319
	0362	0293			
TOWADA	0275				
TOWIKA	0275				
TRIUMPH	0301				
TVA	0250				
<b>U</b>					
UHER	0256				
UNITED QUICK STAR	0245				
UNIVERSUM	0290	0235	0263	0257	0315
	0256	0231	0237	0239	0253
	0271				
<b>V</b>					
VICTOR	0294	0295			
VIDEON	0233	0262	0311	0248	
<b>W</b>					
WELTBlick	0256				
<b>Y</b>					
YAMISHI	0275				
YOKAN	0275				
YOKO	0275	0250	0256		
<b>Z</b>					
ZENITH	0256				
<b>LD</b>					
DENON	0252	0318			
GRUNDIG	0318				
MITSUBISHI	0318				
NAD	0318				
PIONEER	0318				
TELEFUNKEN	0318				
THORN	0322				
<b>DVD</b>					
<b>A</b>					
ACCOUSTIC SOLUTION	0383	0350			
AEG	0894	0333			
AFREY	0386				
AIRIS	0357				
AIWA	0383	0377			
AKAI	0369	0333	0382	0350	0894
	1082				
AKASHI	0346				
ALBA	0384	0350	0381	0357	0370
	0351				
ALL-TEL	0333				
AMES	0383				
AMSTRAD	0350				
AMW	1053	1054			
ANABA	0961				
ANSONIC	0356				
APEX	0921	0384	0357	0911	0390
	0913	1083	0949		
ARENA	0923				
ASPIRE	0952				
A-TREND	0347				
AUDIOSONIC	0382	1062			
AUDIOVOX	0942				
AXION	0942				
<b>B</b>					
B & K	0978				
BAIER	0349				
BAZE	0357				
BEKO	1064				
BLACK DIAMOND	0350				
BLAUPUNKT	0384				
BLU-RAY	1796	1109	1108	1107	1113
	1081	0375			
BLUE NOVA INTERNAT	1051				
BLUE SKY	0375	0373	0357	0350	
BOMAN	0894	0351			

BRANDT	0373	0360	0362		
BRITANIA	1795				
BROKSONIC	0920	0967			
BUSH	0384	0382	0350	0381	0356
<b>C</b>					
CAMBRIDGE	0376				
CELESTIAL	0357				
CENTREX	0357				
CENTRIOS	0932	0951	0954	0955	
CENTRON	0932				
CENTRUM	0346	0926	0928	0350	0927
CINETEC	0350				
CINEVISION	0375				
CLASSIC	0383				
CLATRONIC	0357	0894			
CMI	0923				
COBY	0332	0916	0946	0947	0357
	1051	0948			
CONTEL	1772	0894			
CRITERION	0344				
CROWN	0373	0382			
C-TECH	0341				
CURTIS	0950	0948			
CYBERCOM	0356	0930	0932	0330	0335
	0339	0340	0341	0342	0345
	0352	0358	0371	0923	0375
	0343	0924	0933	0338	0334
	0344	0664	0372	0373	
CYBERHOME	0347	0912	0985	1075	
CYBERLINK	1101				
CYBERMAXX	0356	0930	0373	0932	0330
	0335	0339	0340	0341	0342
	0345	0352	0358	0371	0895
	0896	0897	0898	0899	0900
	0901	0902	0903	0904	0923
	0893	0959	1069	1070	1071
	1067	1066	1068	1117	1118
	0905	0343	0924	0933	0375
	0906	0338	0372	0334	0344
	0664	0894			
CYTRON	0356	0930	0373	0932	0330
	0335	0339	0340	0341	0342
	0345	0352	0358	0371	0380
	0895	0896	0897	0898	0899
	0900	0901	0902	0903	0904
	0923	0893	0959	1069	1070
	1071	1067	1066	1068	1117
	1118	0905	0343	0924	0933
	0375	0906	0338	0372	0334
	0344	0664	0894		
CYBERVISION	1791				
<b>D</b>					
DAEWOO	0353	0354	0965	0355	0347
	0380	0925	0971		
DANSAI	0351				
DAYTRON	0925				
DCE	0356				
DENON	0364	0389			
DENVER	0381	1051	0894		
DENZEL	0392				
DESAY	0958				
DIAMOND	0373	0341			
DIGIFRAME	0930				
DIGIHOME	0350				
DIGITOR	0382				
DIGITREX	0357				
DIGITRON	0386				
DIGIX	0962				
DIK	0356				
DISNEY	0339	0902			
DIVIDO	0380				
DIVX	0375	0932			
DK DIGITAL	0356				
DMTECH	0351	0333			
DRAGON SYSTEMS	0356				
DUAL	0350	0356	0984	0383	0956
	0373	0330	0335	0337	0340
	0392	0341	0342	0345	0352
	0358	0371	0923	0351	0333
	0343	0338	0372	0334	0344
	0664	0375	0924	0933	
DURABRAND	0333	0375	0356	0933	1085
	1086	1087	1088		
DVD 1024	0929				
<b>E</b>					
E-BENCH	0341				
ELTA	0365	0382	0894	0333	
ELTAX	1051				
EMERSON	0380	1057	0339	0375	
ENCORE	0386				
ENZER	0392				
ESA	0956				
EUROLINE	0894				
<b>F</b>					
FARENHEIT	0960				
FERGUSON	0373				
FINLUX	0375	0357	0351		
FINTEC	0350				

FIRSTLINE	0373				
FISHER	0378				
FUNAI	0339				
<b>G</b>					
GE	0384				
GERICOM	1064				
GOLDEN SPHERE	0341				
GOLDSTAR	0375	0907	0972		
GOODMANS	0373	0382	0350	0333	0351
GO-VIDEO	0383	1059	1061	0338	0367
	0971	0351			
GPX	0910				
GRADIENTE	1794	1793	0373		
GRAETZ	0392				
GRAN PRIX	0356				
GRANDIN	0357				
GRUNDIG	0385	0370	0380	0373	0378
	0376	0350	0333		
<b>H</b>					
H & B	0350	0343			
HB	1095	1089			
HAAZ	0341	0342			
HANSEATIC	0375	0351	0333		
HARMON/KARDON	0395				
HCM	0894				
HD-DVD	1796	1110	1109	1108	1107
	1081	0375			
HE	0383				
HITACHI	0367	0368	0392	0387	0350
HITEKER	0357				
HOHER	0356				
HOME ELECTRONICS	0383				
HOMITA	0934	0935	0936	0937	0938
HOYO	0392				
HYUNDAI	0351				
<b>I</b>					
ILO	0959				
INITIAL	0384				
INTEGRA	0374				
INTERTRONIC	0893	0933	0894		
<b>J</b>					
JATON	0392				
JBL	0395				
JDB	0383				
JVC	0361	1058	0362	0400	0964
	0662	1072			
JWIN	1076	1083			
<b>K</b>					
KARCHER	0351				
KAWASHI	0333				
KENDO	0356	0923	0350		
KENNEX	0350				
KENWOOD	0393	0364			
KISS	0392				
KLH	0384				
KONKA	0908	0909			
KOSS	0358	0373			
<b>L</b>					
LASONIC	0341				
LAWSON	0341	0380			
LECSON	0376				
LENCO	1774	0373	0350	0356	
LENOXX	0931	0346	0382		
LG	1800	1798	1797	1117	0375
	0907	0972			
LIFE	0900	0373	1117	1118	0372
LIFETEC	0356	0930	0373	0932	0330
	0335	0339	0340	0341	0342
	0345	0352	0358	0371	0895
	0896	0897	0898	0899	0900
	0901	0902	0903	0904	0923
	0893	0959	1069	1070	1071
	1067	1066	1068	1117	1118
	0905	0343	0924	0933	0375
	0906	0338	0372	0334	0344
	0664	0894			
LIMIT	0341				
LINN	0336				
LITEON	0982	1056	1059	0959	
LODOS	0350				
LOEWE	0370	0375			
LOGIX	0351	0380			
LUMATRON	0332	0342	1051	0350	0383
	0380				
LUXMAN	0367				
LUXOR	0350	0383			
<b>M</b>					
MAGNAVOX	0362	0379	0979	0980	0981
	0370	0350	0914		
MANHATTAN	0350	0380			
MARANTZ	1079	0370	0379	0981	0375
	0362				
MARK	0350				
MASTEC	0335				
MATSUI	0373	0357	0350		
MAXDORF	0894				
MAXIM	0331	0350			
MBO	0396	0383	0382		



MEDIENCOM	0342				
MEDION	1800	1798	1001	0356	0930
	0373	0932	0330	0335	0339
	0340	0341	0342	0345	0352
	0358	0371	0351	0895	0896
	0897	0898	0899	0900	0901
	0902	0903	0904	0923	0893
	0959	1069	1070	1071	1067
	1066	1068	1115	1116	1117
	1118	0905	0343	0924	0933
	0375	0906	0338	0372	0334
	0344	0664	0894		
MEMOREX	0356	0339	0920		
MERIDIAN	0362				
METZ	0368	0350	0922		
MICROMAXX	0356	0893	0930	0373	0932
	0330	0335	0339	0340	0341
	0342	0345	0352	0358	0371
	0895	0896	0897	0898	0899
	0900	0901	0902	0903	0904
	0923	0959	1069	1070	1071
	1067	1066	1068	1117	1118
	0905	0343	0924	0933	0375
	0906	0338	0372	0334	0344
	0664	0894			
MICROMEGA	0370				
MICROSOFT	0399	1100			
MICROSTAR	0356	0930	0373	0932	0330
	0335	0339	0340	0341	0342
	0345	0352	0358	0371	0895
	0896	0897	0898	0899	0900
	0901	0902	0903	0904	0923
	0893	0959	1069	1070	1071
	1067	1066	1068	1117	1118
	0905	0343	0924	0933	0375
	0906	0338	0372	0334	0344
	0664	0894			
MINATO	0349				
MINERVA	0380				
MINTEK	0384				
MIRROR	0349				
mitsubishi	0350	0366			
MONYKA	0392				
MT LOGIC	1062				
MUSTEK	0383				
MXONDA	0373				
MYSTRAL	0356				
<b>N</b>					
NAD	0375	0394			
NAKAMICHI	0398				
NEC	0375				
NEOTEK	0386				
NEUFUNK	0392				
NEVIR	0356				
NEXXTECH	1772	0932	0954	0955	0956
NORCENT	0332	0982	0944	0945	0948
NORDMENDE	0356				
NORIKO	0349				
<b>O</b>					
OCEANIC	1089				
OKANO	0349	0362			
OMNI	0382				
ONIX	0346				
ONKYO	0374	0975			
OPTIMUS	0368	0922			
ORION	0920	0335			
ORITRON	0373				
<b>P</b>					
PACIFIC	0356	0350	0333		
PACKARD BELL	0939	0940	1101	1052	
PALSONIC	0357				
PANASONIC	1107	0401	0364	0403	0970
	0974				
PANDA	0351				
PHILCO	1792				
PHILIPS	1775	0370	0379	0979	0980
	0981	0362	1080	1123	1128
	0969	0339			
PHOCUS	1063	1064			
PHONOTREND	0916				
PIONEER	1109	1108	0368	0977	0922
	0968	0976	1084		
POLAROID	0957	0949			
PORTLAND	0382				
PRINZ	0356				
PRISM	0335				
PRO2	0356	0930	0373	0932	0330
	0335	0339	0340	0341	0342
	0345	0352	0358	0371	0895
	0896	0897	0898	0899	0900
	0901	0902	0903	0904	0923
	0893	0959	1069	1070	1071
	1067	1066	1068	0905	0343
	0924	0933	0375	0906	0338
	0372	0334	0344	0664	0894
PROCASTER	0905				
PROLINE	0373	0357	0333	0376	0397
PROSCAN	0399				

PROSON	0350				
PROSONIC	0332	0341	0349		
PROVIEW	1001				
PROVISION	0381	1051			
<b>Q</b>					
QUADRO	0928				
QUARTEK	1077				
<b>R</b>					
RADIONETTE	0375				
RAITE	0392				
RCA	0399	0384			
REDSTAR	0894	0965			
RELISYS	0923	0895			
REOC	0341				
REX	0346				
ROADSTAR	0350	0383	0382		
RONIN	0397				
ROTEL	0361				
ROWA	0384	0922			
RTL	0923				
<b>S</b>					
SABA	0373	0915	0360		
SAIVOD	0356				
SALORA	0375				
SAMPO	0341	0386	0923	0895	1051
SAMSUNG	1122	1114	1113	1112	0367
	1050	0338	0963	0919	
SANSUI	0340	0920			
SANYO	0350	0333	1060	0378	
SCAN	0380				
SCHAUB LORENZ	1095	0894	1089		
SCHNEIDER	0350	0352	0356	0373	0351
	0894	0333	0380		
SCHWAIGER	0349				
SCIENTIFIC LABS	0341				
SCOTT	0373	0357			
SEG	0350	0341	0392		
SHARP	1796	0371	0394	1055	0350
SHERWOOD	0391				
SHINCO	0384				
SHINSONIC	0384				
SILVA	0894				
SILVA SCHNEIDER	0356				
SILVERCREST	0341	1093	1090	1091	1092
SINGER	0341	0382			
SKYMASTER	0382	0383			
SM ELECTRONIC	0382	0383	0341		
SMART	0350	0380			
SONY	1081	0363	0987	0988	0989
	0402	0986			
SOUNDMASTER	0341				
SOUNDMAX	0341				
SOUNDSTORM	0330				
SOUNDWAVE	0351				
STANDARD	0373				
STRONG	0350				
SUNGALE	0953				
SUPERVISION	0382	0383			
SVA	0349				
SYLVANIA	0339				
SYNN	0341				
<b>T</b>					
TANDBERG	0350				
TANGENT	1051				
TARGA	0375	1115	0959	0891	1117
	0972	1094	1121	0907	
TCM	0900	0356	0930	0373	0932
	0330	0335	0339	0340	0333
	0341	0342	0345	0352	0358
	0371	0923	1119	0343	0924
	0933	0338	0372	0334	0344
	0664				
TEAC	0368	0333	0341	0384	0375
TECHNICS	0364	0399			
TECHNIKA	0356				
TECHWOOD	0394	0350	0370		
TECO	0923	0895			
TEDELEX	0382				
TELEDEVICE	1051				
TELEFUNKEN	0894	0333			
TELETECH	0350				
TENSAI	0373	0382			
TERAPIN	0943				
TEVION	0356	0930	0373	0932	0330
	0335	0337	0339	0340	0341
	0342	0345	0352	0358	0371
	0891	0892	0895	0896	0897
	0898	0899	0900	0901	0902
	0903	0904	0923	0966	0893
	0959	1065	1068	1069	1070
	1071	1067	1066	1117	1118
	0890	0905	0343	0924	0933
	0375	0906	0338	0917	0918
	0372	0334	0344	0664	0894
	1064				
THETA DIGITAL	0368				
THOMSON	0360	0359	0399	1078	
TINY	1051				

TOKAI	0894	0392			
TOKIWA	0380				
TOSHIBA	0973	1110	1120	0362	0983
	0920	1111			
TRANS-CONTINENTS	0356	1051			
TRANSONIC	0357				
TREDEX	0941				
TRUTECH	1075				
U					
UMAX	0382				
UNITED	0333	0348	0357	0894	
UNIVERSUM	0350	0375	0333		
V					
VENTURER	0333				
VESTEL	1771	0350			
VIETA	0380				
VOXSON	0383	0356	0382		
W					
WALKVISION	0384				
WELKIN	0356				
WELLTECH	1098	1105	1106		
WESTAR	0350				
WHARFEDALE	0376	0349	0341	0386	
WILSON	0356				
X					
X-BOX	0399				
XENIUS	0373	0358			
XLOGIC	0341				
XMS	0894				
Y					
YAKUMO	0357	1083	0905		
YAMAHA	1773	0364	0388	0979	0980
	0370				
YAMAKAWA	0397	0392	0382		
YUKAI	0383				
Z					
ZENITH	0375	0907			
<b>DVD Recorders DVD-R, DVD-RW</b>					
A					
APEX	0911				
ARENA	0923				
ASPIRE	0952				
B					
BLUE NOVA INTERNAT	1051				
C					
CENTRIOS	0951				
CMI	0923				
COBY	1051				
CYBERCOM	0923				
CYBERHOME	0912				
CYBERMAXX	0895	0905	0906	0923	0959
	1071	1117			
CYTRON	0895	0905	0906	0923	0959
	1071	1117			
D					
DENVER	1051				
DUAL	0923				
E					
ELTAX	1051				
EMERSON	1057				
G					
GO-VIDEO	0383	1059	1061		
H					
HITACHI	0387				
HB	1089				
I					
ILO	0959				
J					
JVC	1058	1072			
K					
KENDO	0923				
L					
LG	0907				
LIFE	1117				
LIFETEC	0895	0905	0906	0923	0959
	1071	1117			
LITEON	1056	1059	0959		
LUMATRON	1051				
M					
MAGNAVOX	0979	0980			
MEDION	0895	0905	0906	0923	0959
	1071	1117			
MICROMAXX	0895	0905	0906	0923	0959
	1071	1117			
MICROSTAR	0895	0905	0906	0923	0959
	1071	1117			
MUSTEK	0383				
O					
OCEANIC	1089				
P					
PACKARD BELL	0940	1052			
PANASONIC	0403				
PHILIPS	0979	0980	1080	1128	
PHOCUS	1063				

PIONEER	0977	1084			
PRO2	0895	0905	0906	0923	0959
	1071				
PROVISION	1051				
R					
RTL	0923				
S					
SAMPO	1051				
SAMSUNG	1112	1050			
SANYO	1060				
SCHAUB LORENZ	1089				
SHARP	1055				
SONY	0987	0988	0989		
T					
TANGENT	1051				
TARGA	1115	0959	0891	1117	0907
	1121				
TCM	0923				
TELEDEVICE	1051				
TEVION	0890	0891	0895	0905	0906
	0923	0959	1065	1071	1117
THOMSON	0360	0359	1078		
TINY	1051				
TOSHIBA	0973	0983	0362	1111	
TRANS-CONTINENTS	1051				
Y					
YAKUMO	0905				
YAMAHA	0979	0980			
Z					
ZENITH	0907				
<b>TV/DVD Combos DVD &amp; TV</b>					
A					
AKAI	1082	&	1410		
AUDIOSONIC	1062	&	0090		
B					
BEKO	1064	-			
BROKSONIC	0920	-			
C					
CYBERCOM	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
CYBERMAXX	0894	-			
	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
CYTRON	0894	-			
	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
D					
DUAL	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
DURABRAND	0933	&	0228		
	1085	&	1006		
	1085	&	1007		
	1086	&	1008		
	1087	&	1008		
	1088	&	1009		
H					
H & B	0343	&	0228		
HB	1089	&	1011		
G					
GERICOM	1064	-			
I					
INTERTRONIC	0894	-			
L					
LIFETEC	0894	-			
	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
M					
MEDION	0894	-			
	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
	-		1001		
MEMOREX	0920	-			
MICROMAXX	0894	-			
	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
MICROSTAR	0894	-			
	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
MT LOGIC	1062	&	0090		
O					
OCEANIC	1089	&	1011		
ORION	0920	-			
P					
PHILIPS	0339	&	0181		
PHOCUS	1064	-			
PRO2	0894	-			

	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
PROVIEW	-	-	1001		
<b>S</b>					
SANSUI	0920	-	-		
SCHAUB LORENZ	1089	&	1011		
<b>T</b>					
TCM	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
	1119	-	-		
TEVION	0894	-	-		
	0343	&	0228		
	0924	&	0210		
	0933	&	0228		
	1064	-	-		
TOSHIBA	0920	-	-		
<b>V</b>					
VESTEL	1771	&	0215		
<b>DVD/VCR Combos</b>					
DVD & VCR					
<b>A</b>					
APEX	0949	-	-		
<b>B</b>					
BROKSONIC	0920	-	-		
	0967	-	-		
<b>C</b>					
CINEVISION	0375	&	0256		
CYBERCOM	0338	-	-		
	0375	&	0256		
CYBERMAXX	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
CYTRON	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
<b>D</b>					
DAEWOO	0971	-	-		
DUAL	0338	-	-		
	0375	&	0256		
<b>E</b>					
EMERSON	0339	&	0231		
	0375	&	0256		
<b>F</b>					
FUNAI	0339	&	0231		
<b>G</b>					
GO-VIDEO	0338	-	-		
	0367	-	-		
	0971	-	-		
GOLDSTAR	0375	&	0256		
<b>H</b>					
HITACHI	0387	&	0231		
<b>J</b>					
JVC	0400	-	-		
<b>L</b>					
LG	0907	-	-		
	0375	&	0256		
LIFETEC	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
<b>M</b>					
MAGNAVOX	0914	&	0285		
MEDION	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
MICROMAXX	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
MICROSTAR	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
<b>P</b>					
PANASONIC	0970	-	-		
PHILIPS	0969	&	0285		
PIONEER	1084	-	-		
POLAROID	0949	-	-		
PRO2	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
<b>S</b>					
SAMSUNG	0338	-	-		
	0963	-	-		
SANSUI	0920	-	-		
SANYO	0378	&	0258		
SILVERCREST	-	&	0256		
SONY	0402	-	-		
SYLVANIA	0339	&	0231		

<b>T</b>					
TARGA	0375	&	0256		
	0907	-	-		
	0375	&	1041		
TCM	0338	-	-		
	0375	&	0256		
TEVION	0338	-	-		
	0896	-	-		
	0906	-	-		
	0375	&	0256		
TOSHIBA	0362	-	-		
<b>Z</b>					
ZENITH	0375	&	0256		
<b>HDD Digital Video Recorders</b>					
(Hard Disk Drive, DVR, PVR, etc)					
<b>A</b>					
AMSTRAD	0555	-	-		
ARCON	1144	-	-		
ARION	1238	-	-		
<b>B</b>					
BSKYB	0555	-	-		
BUSH	1261	-	-		
<b>C</b>					
CANAL SATELLITE	0599	-	-		
CANAL+	0599	-	-		
COMAG	1231	-	-		
CONRAD	1156	-	-		
CYBERCOM	0412	0423	0514		
CYBERMAXX	0905	0412	0423	0514	0644
	0653	1130	0959	1071	1117
CYTRON	0905	0412	0423	0514	0644
	0653	1130	0959	1071	1117
<b>D</b>					
DIGIFUSION	0647	-	-		
DIGIHOME	1262	-	-		
DMT	0412	-	-		
DREAMBOX	0658	-	-		
DUAL	0412	0423	0514		
<b>E</b>					
ECHOSTAR	0659	-	-		
EMTEC	1096	1097	-		
EUROSKY	1156	-	-		
<b>F</b>					
FORCE	0553	-	-		
FORTEC STAR	0470	-	-		
FOXTEL IQ	1225	-	-		
FREEBOX	1182	-	-		
<b>G</b>					
GLOBO	1156	-	-		
GOODMANS	1261	-	-		
<b>H</b>					
HB	1214	-	-		
HIRSCHMANN	1156	-	-		
HITACHI	1262	-	-		
HOMECAST	1223	-	-		
HUMAX	1260	1259	1250	0651	
HYUNDAI	0486	-	-		
<b>I</b>					
ILO	0959	-	-		
<b>J</b>					
JVC	1072	-	-		
<b>K</b>					
KATHREIN	1221	1197	-		
KOSCOM	1144	-	-		
<b>L</b>					
LASAT	1156	1157	-		
LIFE	1117	-	-		
LIFESAT	0412	0423	0514		
LIFETEC	0905	0412	0423	0514	0644
	0653	1130	0959	1071	1117
LG	1800	1798	1117		
LITEON	0959	-	-		
LOGIK	1263	-	-		
LORENTZEN	1156	-	-		
LOEWE	1399	-	-		
<b>M</b>					
MARMITEK OCTOPUS	0655	-	-		
MEDION	1800	1798	1257	0905	0412
	0423	0514	0644	0653	1130
	0959	1071	1139	1115	1181
	1117	-	-		
MICROMAXX	0905	0412	0423	0514	0644
	0653	1130	0959	1071	1139
	1117	-	-		
MICROSTAR	0905	0412	0423	0514	0644
	0653	1130	0959	1071	1117
MORETV	0644	1130	1181		
<b>N</b>					
NEUF TELECOM	1196	-	-		
NEUF TV	1196	-	-		
<b>P</b>					
PACE	1225	0555	0453		
PACKARD BELL	1052	-	-		
PANASONIC	0403	-	-		
PHILIPS	1775	1128	0242		
PHOCUS	1063	-	-		

PINNACLE	0654				
PIONEER	0977				
PRO2	0905	0412	0423	0514	0644
	0653	1130	0959	1071	
PROCASTER	0905				
<b>R</b>					
RADIX	1152				
<b>S</b>					
SAGEM	0599	1143	1158		
SAMSUNG	1112				
SCHAUB LORENZ	1214				
SCHWAIGER	1231	1157	1156	1152	1132
	0514	0412			
SIEMENS	1157				
SKARDIN	1160				
SKY	1151				
SKY DIGITAL	0555				
SKY+	0555				
SKYMASTER	0412	0506	1165	1159	1160
SKYPEX	1156				
SMART	1246	1244			
SM ELECTRONIC	0412	0506	1165	1159	1160
SONY	0987	0988	0989		
<b>T</b>					
TARGA	1115	1117	1195		
TCM	0412	0423	0514		
TECHNIKA	1262				
TECHNOTREND	1230				
TELEFONICA	1227				
TEVION	0890	0905	0412	0423	0514
	0644	0653	1130	0959	1065
	1071	1117			
THOMSON	0532	0242	0326	1156	1078
TIVO	0242				
TONBURY	1159				
TOPFIELD	1204	1203	0506		
TOSHIBA	0983	1111			
TVONICS	1263				
<b>U</b>					
UNIVERSUM	1156				
<b>W</b>					
WHARFEDALE	1262				
WYSI	1156				
<b>Y</b>					
YAKUMO	0905				
<b>Cable Boxes</b>					
<b>A</b>					
AUSTAR	1224	0494			
<b>B</b>					
BMB	0636				
BT	0554				
<b>C</b>					
CABLE AND WIRELESS	0606				
CABLECRYPT	0474				
CABLETIME	0448	0449	0450		
CANAL PLUS	0474				
CLYDE CABLEVISION	0452				
COMCRYPT	0474				
CRYPTOVISION	0458				
<b>E</b>					
EURODEC	0603				
<b>F</b>					
FILMNET	0474				
FILMNET CABLECRYPT	0474				
FILMNET COMCRYPT	0474				
FOXTEL	1224	0602			
FOXTEL IQ	1225				
<b>G</b>					
GEC	0452				
GI	0494	0554			
<b>I</b>					
IMPULSE	0554				
<b>J</b>					
JERROLD	0554	0494			
<b>K</b>					
KABELVISION	0554				
<b>L</b>					
LYONNAISE	1183				
<b>M</b>					
MARMITEK	0636				
MELITA	0554				
MNET	0602	0474			
MOTOROLA	0494				
MOVIE TIME	0551				
MULTICHOICE	0474	0602			
<b>N</b>					
NOKIA	0564				
NOOS	1143	1158	1175	1183	
NTL	0606	1200			
NUMERICABLE	0603				
<b>O</b>					
OPTUS	1224	0494			
<b>P</b>					
PACE	0606				
PHILIPS	0487				
PIONEER	0518	0521			

PVP	0554				
<b>S</b>					
SAGEM	0604				
SAMSUNG	1148				
SCIENTIFIC ATLANTA	0524	0525			
SMART	1174				
STS	0551				
<b>T</b>					
TELE+1	0474				
TELEPIU	0474				
TELEWEST	0606	0554			
THOMSON	1189				
<b>U</b>					
UNITED	0554				
UPC	1143	1175	1184		
<b>V</b>					
VIRGIN MEDIA	0606				
VISIONETICS	1185				
VISIOSAT	0487				
<b>SAT</b>					
<b>A</b>					
@SAT	1147				
@SKY	1138				
ADECQ	1340				
AKAI	0552				
ALBA	0508	0562	0405	0407	
ALDES	0408	0409			
ALLSAT	0462	0410	0552		
ALLSONIC	0408	0428			
AMPERE	0422				
AMSTRAD	0584	0555	0541	0415	0416
	0417	0419			
ANKARO	0408	0428	0424		
ANTTRON	0405	0407			
APOLLO	0405				
ARCOM	1174	1165			
ARCON	0415	0422	1155	1144	1153
	0424	0463	1154		
ARENA	1222				
ARION	1238				
ARMSTRONG	0419				
ARNION	1147				
ASAT	0552				
ASCII	1138				
AST	0435				
ASTON	0594	0406			
ASTRA	0429	0419	0431	0432	0502
ASTRO	0428	0439	0569	0407	0409
AUDIOTON	0462	0407			
AURORA	0602				
AUSTAR	1224	0602	0643	0642	
AXIS	0428	0415	0432	0456	
<b>B</b>					
BARCOM	0424				
BEST	0428	0424			
BLAUPUNKT	0439				
BOCA	0419	0502			
BRAIN WAVE	0444	0549	1131		
BRANDT	0565	0566	0567	0574	
BSKYB	0584	0555			
BT SATELLITE	0574				
BUSH	0508	0562	0410		
<b>C</b>					
CANAL SATELLITE	0569	0599			
CANAL+	0569	0599			
CHAPARRAL	0507				
CHESS	0547	0586			
CITYCOM	0508	0640	0485	0459	
CLATRONIC	0444				
CLEMENS KAMPHUS	0491				
CNT	0409				
COLUMBUS	0477				
COMAG	1255	1237	1233	1231	0471
COMMLINK	0408				
COMTECH	0456				
CONDOR	0428	0640			
CONNEXIONS	0438	0454			
CONRAD	0640	1156			
CONTEC	0456	0459			
COSAT	0462				
COSHIP	0427				
CROWN	0419				
CYBERCOM	0412	0413	0423	0428	0442
	0493	0504	0511	0514	0546
	0566	0583	0586	0587	0618
	0619				
CYBERMAXX	0412	0413	0423	0428	0442
	0466	0478	0484	0493	0504
	0511	0514	0535	0546	0566
	0583	0586	0587	0618	0619
	0644	0650	0652	0653	1130
	1138	1137			
CYTRON	0412	0413	0423	0428	0442
	0466	0478	0484	0493	0504
	0511	0514	0535	0546	0566
	0583	0586	0587	0618	0619

	0644	0650	0652	0653	1130
	1138	1137			
<b>D</b>					
DAERYUNG	0438				
DANSAT	0410				
D-BOX	0564	0604			
DECCA	0460				
DEW	0456				
DIAMOND	0461				
DIGIALITY	0640				
DIGIQUEST	1147	0485	0427		
DIGITAL M SERIE	1249				
DISKXPRESS	0424	0454			
DITRISTRAD	0462				
DMT	0412				
DNT	0438	0552			
DRAKE	0557	0463			
DREAMBOX	0658				
DREAM MULTIMEDIA	0658				
DSTV	0602				
DUAL	0412	0413	0423	0428	0493
	0504	0511	0566	0583	0586
	0587	0618	0514		
<b>E</b>					
ECHOSTAR	0640	0581	0586	0425	0481
	0578	0579	0580	0657	0659
	0464	0465	0467		
EINHELL	0408	0417	0405	0419	
ELEKTA	0409				
ELTA	0428	0462	0405	0552	
EMANON	0405				
EMME ESSE	0428	0508	0491		
EMTECH	1162				
ENIGMA	1248				
EP SAT	0508	0491			
E-TEK	1140				
EUROPHON	0640				
EUROSAT	0419				
EUROSKY	0428	0640	1156	0419	
EUROSPACE	0468				
EUROSTAR	0438	0419			
EVA	0588	0589			
EXATOR	0405	0407			
<b>F</b>					
FERGUSON	0508	0472	0603	0410	0473
FIDELITY	0415	0417			
FINLANDIA	0508				
FINLUX	0508	0429	0608	0475	0480
	0487				
FINNSAT	0603	0456			
FORCE	0577	0553	0535		
FORTEC STAR	0470				
FOXTEL	1224	1225	0602		
FOXTEL IQ	1225				
FRACARRO	0562				
FRANCE SATELLITE/TV	0477				
FREECOM	0405	0489			
FTE	0422	0496			
FUBA	0548	0439	0428	0438	0405
	0424	0431	0477	0480	0552
FUNTACH	0587				
<b>G</b>					
GALAXIS	0428	0408	0462	0478	0484
	0485	0535	0582	0583	0602
	0619	0432	0456		
GALAXY	0424				
GLOBECAST	1141				
GLOBO	1156				
GMI	0419				
GOLDSTAR	0489				
GOODING	0483				
GOODMANS	0508				
GRANADA	0429				
GRANVISION	1235	1234			
GROTHUSEN	0405	0489			
GRUNDIG	0439	0436	0483	0495	0508
	0544	0469	0602	0584	0407
	0550				
<b>H</b>					
HANDAN	0547	1167			
HANSEATIC	0504				
HANTOR	0444	0405			
HANURI	0409				
HB	1162	0413	1214	1215	1216
HEAD	1253	1252	1251		
HELIOCOM	0422				
HIRSCHMANN	0439	0522	0547	0548	1156
	1165	1174	0487	0488	0491
	0558				
HISAWA	0444				
HITACHI	0508	0537			
HOMECAST	1222	1223	1162		
HOUSTON	0462				
HUMAX	1260	1259	1258	1250	0485
	0517	0582			
HUTH	0408	0411	0444	0462	0419
	0491				
HYUNDAI	0486				

<b>I</b>					
ID DIGITAL	0485				
IMPERIAL	0562				
INNOVATION	0428	0493	0504	0511	0583
	0586	0587	0618		
INTERTRONIC	0419				
INTERVISION	0462				
IRDETO	0602				
ITT/NOKIA	0429	0508	0548	0454	0487
	0537				
<b>J</b>					
JOHANSSON	0444				
JSR	0462				
JVC	0483				
<b>K</b>					
KAON	1147				
KATHREIN	1221	1197	0549	0617	0631
	0607	0635	0439	0459	0496
	0507	0552			
KOSCOM	1144				
KOSMOS	0489	0491	0496		
KR	0407				
KREILING	0549	0631	1137	1232	
KREISELMEYER	0439				
KYOSTAR	0405				
<b>L</b>					
LASAT	0428	0565	0566	0567	0630
	1156	1157	0409	0502	
LENCO	0405	0489	0503		
LENG	0444				
LENNOX	0462				
LENSON	0479				
LG	0489				
LIFE	0583				
LIFESAT	0412	0413	0423	0428	0442
	0493	0504	0511	0514	0546
	0566	0583	0586	0587	0618
	0619				
LIFETEC	0412	0413	0423	0428	0442
	0466	0478	0484	0493	0504
	0511	0514	0535	0546	0566
	0583	0586	0587	0618	0619
	0644	0650	0652	0653	1130
	1138	1137			
LION	0468				
LORENTZEN	1156				
LORRAINE	0489				
LUPUS	0428				
LUXOR	0417	0429	0548	0537	
<b>M</b>					
MACAB	0603				
MANHATTAN	0462	0508	0557	0633	0421
	0409				
MARANTZ	0552				
MARMITEK	0641				
MARMITEK OCTOPUS	0655				
MASCOM	0409				
MASPRO	0483	0508	0507	0558	
MATSUI	0483	0574			
MB	0504				
MBOX	0442				
MEDIABOX	0569				
MEDIACOM	0506				
MEDIAMARKT	0419				
MEDIASAT	0569	0432			
MEDION	1257	1217	0412	0413	0423
	0428	0442	0466	0478	0484
	0493	0504	0511	0514	0535
	0546	0566	0583	0586	0587
	0618	0619	0644	0650	0652
	0653	1130	1139	1138	1137
	1181				
MEGA	0552				
METRONIC	0408	0575	0612	0613	0614
	0615	0632	0409	0424	0405
	0407				
METZ	0439				
MICRO TECHNOLOGY	0468				
MICROMAXX	0412	0413	0423	0428	0442
	0466	0478	0484	0493	0504
	0511	0514	0535	0546	0566
	0583	0586	0587	0618	0619
	0644	0650	0652	0653	1130
	1139	1138	1137		
MICROSTAR	0412	0413	0423	0428	0442
	0466	0478	0484	0493	0504
	0511	0514	0535	0546	0566
	0583	0586	0587	0618	0619
	0644	0650	0652	0653	1130
	1138	1137			
MINERVA	0483	0439			
MITSUBISHI	0508	0439	0574		
MITSUMI	0502				
MORETV	0644	0423	1130	1181	
MORGAN SYDNEY	0611				
MORGANS	0611	0419	0502	0552	
MULTICHOICE	0602				
MULTISTAR	0496				

MULTITEC	0586	0587			
MURATTO	0437	0489			
<b>N</b>					
NAVEX	0444				
NEC	0509	0510			
NEOTION	1138				
NEUHAUS	0462	0479	0432		
NEXTWAVE	0414	0585			
NIKKO	0419				
NOKIA	0530	0564	0425	0429	0508
	0548	0563	0531	0454	0487
	0604				
NOMEX	0622				
NORDMENDE	0549	0472	0508	0603	0405
	0409				
NOVIS	0444				
<b>O</b>					
OAK	0424				
OCEANIC	0461	0468			
OCTAGON	0405	0407	0456		
OKANO	0419	0491	0496		
OPTEX	0462	0459	0656		
OPTUS	1224	0602			
ORBIT	0435				
ORBITECH	0405				
ORIGO	0468				
OSAT	0407				
OTTO VERSAND	0439				
<b>P</b>					
PACE	0584	0555	0439	0559	0527
	0508	0410	0617	1225	
PACIFIC	0461				
PALCOM	0479	0431	0477		
PALLADIUM	0483	0419			
PALTEC	0431				
PANASONIC	0584	0508	0542		
PANDA	0508	0410			
PANSAT	0490				
PANTECH	0591				
PBI	1138				
PHILIPS	0552	0436	0483	0493	0495
	0508	0543	0434	0569	0574
	0605	0618	0455	0561	0550
	0456	0515	0604		
PHOENIX	0456				
PHONOTREND	0408	0462	0491	0652	
PILOTIME	0599				
PINNACLE	0654				
PIONEER	0569				
POLSAT	0603				
POLYTRON	0459				
PREDKI	0444				
PREMIER	0569				
PREMIERE	0604	0569	0564	0542	0485
	0462	0442			
PREMIUM X	1134				
PRIESNER	0445	0419			
PRO2	0412	0413	0423	0428	0442
	0466	0478	0484	0493	0504
	0511	0514	0535	0546	0566
	0583	0586	0587	0618	0619
	0644	0650	0652	0653	1130
	1138	1137			
PROFI	0503				
PROMAX	0508				
PROSAT	0408	0562			
PROTEK	0461				
PROVISION	0409				
<b>Q</b>					
QUADRAL	0408	0428			
QUELLE	0439	0417			
QUIERO	0603				
<b>R</b>					
RADIOLA	0552				
RADIX	0630	0438	0632	1152	
RAINBOW	0407				
REDIFFUSION	0510				
REDPOINT	0432				
REDSTAR	0428				
RFT	0408	0552			
RUEFACH	0503				
<b>S</b>					
SAB	1137	1144	1145	1146	1147
SABA	0472	0508	0543	0556	0562
	0565	0571	0572	0573	0574
	0575	0409	0468		
SABRE	0508				
SAGEM	0570	0604	0599	0603	0648
SAKURA	0456				
SALORA	0429	0527	0509	0520	
SAMSUNG	0426	0405	0506		
SAT	0415	0435	0437		
SAT+	0546	1137			
SATCOM	0640	0504	0523		
SATEC	0508				
SATPARTNER	0444	0405	0407	0409	0489
	0491				
SCHAUB LORENZ	1147	1162	1214	1215	1216

SCHNEIDER	0428	0455	0506	0511	0583
	0586	0587	0618		
SCHWAIGER	1255	1236	1233	1231	1157
	1156	1131	0567	0565	0428
	0409	0411	0412	0413	0427
	0430	0433	0440	0504	0508
	0516	0566	0573	0575	0576
	0577	0582	0514	0583	0585
	0587	0598	0616	0630	0631
	0633	0635	1132	1133	1147
	1152	1173	0459		
SEEMANN	0438	0419	0432		
SEG	0428	0444	0504	0541	0631
	0634	0405			
SELECO	0462				
SIEMENS	0439	1157			
SILVA	0489				
SKARDIN	0432	0586	0546	1160	
SKY	0555	0584	1151		
SKY DIGITAL	0584	0555			
SKY+	0555				
SKY HD	1151				
SKY ITALIA	0584	0555			
SKYMASTER	0408	0412	0504	0506	0546
	0547	0586	0587	0588	0589
	0590	0591	0592	0621	1140
	1138	1159	1161	1160	1162
	1167	1244			
SKYMAX	0552				
SKYPEX	1156				
SKYPLUS	1138				
SKYVISION	0462				
SMART	1249	1248	1247	1246	1244
	1243	1241	1240	1234	1174
	1165	1133			
SM ELECTRONIC	0408	0412	0504	0506	0546
	0547	0586	0587	0588	0589
	0591	0621	1140	1138	0592
	1159	1161	1160	1162	1167
SONY	0584	0569	0418	0446	
SR	0472	0419	0502		
STARBOX	0427				
STAR TRAK	0405				
STARLAND	0586				
STARRING	0444				
STRONG	0562	0428	0602	0545	0454
	0489	0405	0407		
SUMIDA	0419				
SUNSTAR	0527	0419	0502		
<b>T</b>					
TANDBERG	0603				
TANDY	0407				
TANTEC	0508	0479	0477		
TARGA	1195				
TATUNG	0460				
TCM	0412	0413	0423	0428	0442
	0493	0504	0511	0514	0546
	0566	0583	0586	0587	0618
	0619				
TECHNIHALL	0416				
TECHNISAT	1219	1220	0506	0438	0479
	0569	0623	0528	0529	
TECHNOMATE	0441	1142			
TECHNOTREND	1230	1173	1147	1131	
TECO	0419	0502			
TELASAT	0640				
TELEFUNKEN	0560	0508	0565	0566	0567
	0574	0405			
TELEKA	0438	0640	0407	0419	
TELEMASTER	0409				
TELESAT	0504				
TELESTAR	1138	0479	0569		
TELEVES	0508	0610	0611		
TELEWIRE	0462				
TEN HAAFT	0423				
TEVION	0412	0413	0423	0428	0442
	0466	0478	0484	0493	0504
	0511	0514	0535	0546	0566
	0583	0586	0587	0618	0619
	0644	0650	0652	0653	1130
	1140	1138	1137		
THOMSON	0472	0601	0570	0574	0492
	0508	0560	0568	0569	0603
	0427	1156			
THORENS	0461				
THORN	0508	0410	0473		
TIOKO	0459				
TONBURY	0445	1159			
TONNA	0546	0508	0462		
TOPFIELD	1205	1204	1203	0497	0505
	0506				
TPS	0570				
TPS PLATINUM	1178				
TRIAD	0435	0437	0533	0489	
TRIASAT	0480				
TRIAx	0439	0479	0565	0609	0619
TWINNER	0610	0611			
<b>U</b>					

UNIDEN	0534				
UNISAT	0419	0456			
UNITOR	0444	0424			
UNIVERSUM	0439	0483	1156	0475	0487
<b>V</b>					
VANTAGE	1254				
VARIOSTAT	0439				
VECTOR	0468				
VENTANA	0552				
VIA DIGITAL	0568				
VIA SAT	0568				
VISIOSAT	0594	0444	0462	0586	0593
	0595	0596	0597		
VIVANCO	0536	0624			
VORTEC	0405				
V-TECH	0437	0435	0515	0537	
<b>W</b>					
WEVASAT	0508				
WEWA	0508				
WINERSAT	0444				
WISI	0435	0437	0438	0439	0508
	0533	0538	0539	0540	0597
	0625	0626	0627	0628	0629
WITTENBERG	0415				
WOORISAT	0409				
WORLDSAT	0631				
WYSI	1156				
<b>X</b>					
XTREME	1147				
<b>Z</b>					
ZEHNDER	1137	1235	1234	1138	0428
	0437	0635	0541	0631	0632
	0409	0424	0496		
ZINWELL	0485				
ZODIAC	0407				

#### ADSL (BROADBAND)

ALICE TV	1158				
DARTY	1158				
FRANCE TELECOM	1158				
FREEBOX TV	1176	1182			
MALIGNE TV	1158	1180			
MAXDOME	1239				
NEUF TELECOM	1179	1196			
NEUF TV	1179	1196			
NOOS	1143	1158	1175	1183	
NUMERICABLE	1183				
ORANGE	1183	1158	1180		
SAGEM	1158	1177			
SAMSUNG	1149				
THOMSON	1175	1180			
TPS ADSL	1158	1179	1180		
UPC	1143	1158	1175		
VERSATEL	1149				

#### DVB-T Terrestrial Digital TV (DTV, Freeview, iDTV, etc)

<b>A</b>					
ADECQ	1226				
ALBA	0451	0646			
ARCOM	1242				
<b>B</b>					
BUSH	1261	0647	0451	0032	
BRAIN WAVE	0476				
<b>C</b>					
CANAL +	1177				
COMAG	1229				
CYBERMAXX	0645	0650			
CYTRON	0645	0650			
<b>D</b>					
DIGENIUS	0645				
DIGIFUSION	0647				
DIGIHOME	1262				
DIGIO2	1150				
DIGIPAL	1218				
DMT	0412				
DURABRAND	0526				
<b>E</b>					
ECHOSTAR	0657				
EMTECH	0476				
FREEBOX	1182				
<b>F</b>					
FREEVIEW	0447	0451	0453	0457	0482
	0512	0513	0519	0526	0532
	0600	0646	0647	0648	0649
	0651				
<b>G</b>					
GbSAT	0476				
GERICOM	0443				
GOODMANS	1261	0526	0451		
GOODWAY	1163	1164			
GRUNDIG	0512	1172			
<b>H</b>					
HAUPPAUGE	0482				
HB	1011	1211	1213	0476	
HITACHI	1262	0526			

HOMECAST	0476				
HUMAX	0651				
<b>I</b>					
INTERSTAR	0476				
<b>J</b>					
JEPSSSEN	0476				
JVC	0526				
<b>K</b>					
KATHREIN	1197				
<b>L</b>					
LABGEAR	0513				
LASAT	1156				
LIDCOM	0451				
LIFETEC	0645	0650			
LOGIK	1263				
<b>M</b>					
MARMITEK OCTOPUS	0655				
MATSUI	0649	0526	0451		
MEDION	0645	0650			
MICO	1135				
MICROMAXX	0645	0650			
MICROSTAR	0645	0650			
<b>N</b>					
NOKIA	0519	0531			
NOOS	1183				
<b>O</b>					
OCEANIC	1011				
OGGLE	1136				
ON-DIGITAL	0527	0531	0620		
OPTEX	0656				
<b>P</b>					
PACE	0453	0527			
PACIFIC	0526				
PANASONIC	0072	0403			
PHILIPS	0600				
PIONEER	0457	0620			
PREMIERE	0600	0519			
PRO2	0645	0650			
<b>R</b>					
REBOX	0476				
<b>S</b>					
SAGEM	0648	1143			
SCHAUB LORENZ	1011	1211	1212	1213	0476
SCHWAIGER	1156	1229	1173	0630	
SHARP	0059				
SKARDIN	0656				
SKYMASTER	1166	1165	1164	1163	1140
	0656	0412			
SMART	1247	1245	1242	1165	1133
SM ELECTRONIC	0412	0656	1165	1163	1164
SONY	0447				
<b>T</b>					
TCM	1413	1017	1119		
TECHNIKA	1262				
TECHNISAT	1218				
TECHNOTREND	1173				
TELEVES	0476				
TEVION	0645	0650			
THOMSON	0427	0532			
TOPFIELD	1204	0506			
TOP-UP TV	0527	0531	0657		
TVONICS	1263				
<b>W</b>					
WHARFEDALE	1262				
WORLDSAT	0476				
<b>Y</b>					
YUNG FU	1166				

#### Home Cinema Systems DVD & AUDIO

<b>A</b>					
AIWA	0377	-			
AMW	1054	-			
<b>C</b>					
CENTRUM	0927	-			
COBY	0948	-			
CRITERION	0344	&	0775		
CURTIS	0948	-			
CYBERCOM	0334	-			
	0372	-			
	0344	&	0775		
CYBERMAXX	0334	-			
	0372	-			
	0344	&	0775		
	1069	-			
	1066	-			
	1118	-			
CYTRON	0334	-			
	0372	-			
	0344	&	0775		
	1069	-			
	1066	-			
	1118	-			
<b>D</b>					
DUAL	0334	-			
	0372	-			
	0344	&	0775		

DURABRAND	0375	-		
<b>F</b>				
FISHER	0378	-		
<b>J</b>				
JVC	0662	-		
	0964	-		
<b>K</b>				
KOSS	0373	-		
<b>L</b>				
LENCO	1774	-		
LENOXX	0931	-		
LG	0972	-		
	1797	-		
LIFE	1118	-		
LIFETEC	0334	-		
	0372	-		
	0344	&	0775	
	1069	-		
	1066	-		
	1118	-		
<b>M</b>				
MEDION	0334	-		
	0372	-		
	0344	&	0775	
	1069	-		
	1066	-		
	1118	-		
MICROMAXX	0334	-		
	0372	-		
	0344	&	0775	
	1069	-		
	1066	-		
	1118	-		
MICROSTAR	0334	-		
	0372	-		
	0344	&	0775	
	1069	-		
	1066	-		
	1118	-		
<b>N</b>				
NORCENT	0948	-		
<b>O</b>				
ONKYO	0975	-		
<b>P</b>				
PANASONIC	0974	-		
PHILIPS	0370	&	0734	
PIONEER	0968	-		
	0976	-		
PRO2	0334	-		
	0372	-		
	0344	&	0775	
	1069	-		
	1066	-		
<b>S</b>				
SAMSUNG	0919	-		
	1114	-		
SONY	0986	-		
<b>T</b>				
TARGA	0972	-		
	0375	&	1041	
TCM	0334	-		
	0344	&	0775	
TEVION	0334	-		
	0372	-		
	0892	-		
	0917	-		
	0918	-		
	0344	&	0775	
	1069	-		
	1066	-		
	1118	-		
<b>W</b>				
WELLTECH	1098	-		
	1105	-		
<b>Auxiliary Set-Top Boxes</b>				
<b>Web &amp; Computer TV</b>				
BUSH	0039			
CYBERLINK	1101			
GERICOM	0443			
HAUPPAUGE	0482			
HAUPPAUGE	1198			
NOW TV	1186			
PACKARD BELL	1101			
PANASONIC	0542			
PINNACLE	1199	1201	1202	
PREMIERE	0542			
TELEFONICA	1227			
THOMSON	0603			
<b>Media Receivers</b>				
SONY NETWORK	0446			
MEDIA RECEIVER				

<b>Scart Switch Boxes</b>					
COUNTRYMAN	1168				
FUNK	1170				
MARMITEK	0641				
SKARDIN	1169				
SKYMASTER	1169				
VIVANCO	0684				
<b>Digital Set Top Boxes</b>					
ADECO	1340				
ECHOSTAR	0657				
SKYMASTER	1166				
TEVION	0650	0645	0423		
YUNG FU	1166				
<b>Misc. Set Top Boxes</b>					
PARDY LIGHT BOX	1171				
<b>Entertainment Box</b>					
EMTEC	1096	1097			
Home Server	1228				
DMA	1228				
MEDION	1228				
<b>Video On Demand</b>					
MAXDOME	1239				
<b>CD Players</b>					
<b>A</b>					
ADCOM	0848				
AIWA	0849	0850	0851	0751	
AKAI	0853	0854	0855		
ALBA	0856				
ARCAM	0732				
<b>B</b>					
BESTAR	0859				
BSR	0860				
BUSH	0661				
<b>C</b>					
CARRERA	0663				
CLASSIC	0807				
CONDOR	0860				
CYBERCOM	0843	0664	0668	0674	0675
	0694	0730	0742	0743	0744
	0745	0746	0747	0801	0802
	0803	0807	0809	0818	0819
CYBERMAXX	0843	0664	0668	0674	0675
	0694	0730	0742	0743	0744
	0745	0746	0747	0801	0802
	0803	0807	0809	0818	0819
CYTRON	0843	0664	0668	0674	0675
	0694	0730	0742	0743	0744
	0745	0746	0747	0801	0802
	0803	0807	0809	0818	0819
<b>D</b>					
DENON	0665	0666			
DUAL	0843	0848	0664	0668	0675
	0694	0730	0742	0743	0744
	0745	0746	0747	0798	0801
	0802	0803			
<b>E</b>					
E-BENCH	0811				
ELTA	0878	0667	0668	0693	0694
	0745				
EMERSON	0848	0859			
<b>F</b>					
FISHER	0669				
<b>G</b>					
GENEXXA	0859	0671	0672	0673	0675
	0676	0677			
GOLDSTAR	0663				
GOODMANS	0678	0679			
GRUNDIG	0680	0697	0698	0732	
<b>H</b>					
HARMON/KARDON	0683				
HITACHI	0848	0685	0686		
<b>I</b>					
INNOVATION	0730	0742	0743	0744	0745
	0746	0747			
<b>J</b>					
JVC	0662	0687			
<b>K</b>					
KENWOOD	0669	0688	0689	0690	0762
<b>L</b>					
LIFE	0823				
LIFETEC	0823	0843	0664	0668	0674
	0675	0694	0730	0742	0743
	0744	0745	0746	0747	0801
	0802	0803	0807	0809	0818
	0819				
LG	0663				
LINN	0732				
LUXMAN	0691				
<b>M</b>					
MAGNUM	0730	0742	0743	0744	0745
	0746	0747			





